

Self-Calibrating Measurements of the Density and Velocity of Sound from the Reflection of Ultrasound at Two Solid-Liquid Interfaces

Margaret Stautberg Greenwood
Pacific Northwest National Laboratory
P. O. Box 999
Richland, WA 99352
Margaret.greenwood@pnl.gov


157th Meeting of
The Acoustical Society of America
Portland, Oregon
18-22 May 2009



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Design and Objectives



► Objectives

- Obtain multiple reflections for both transducers
- Both measurements are self-calibrating
- Determine the reflection coefficients at each solid-liquid interface
- For shear wave multiple reflections, show that experimental values are in agreement with theoretical values
- Use two reflection coefficients to determine the density of the liquid and the velocity of sound in the liquid

Previous Work Using Longitudinal Wave Transducer


- ▶ Use multiple reflections for transducer C and determine acoustic impedance Z of liquid
- ▶ Measure time-of-flight (TOF) across pipeline to measure velocity of sound in liquid c
- ▶ Density = Z / c
- ▶ References:
 - *Journal of Fluids Engineering* **126**, 189-192 (2004)
 - *Ultrasonics* **42**, 563-567 (2004)
- ▶ Goal: Eliminate TOF measurement by using another transducer at a non-normal incident angle.




Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965


Advantage of Using Shear Wave Transducer



Any Angle θ



Angle $\theta < 33^\circ$



Angle $\theta > 33^\circ$
Large RC for $\theta = 45^\circ$

More Energy
in Reflected
Wave


↓
More Echoes




Proudly Operated by Battelle Since 1965

Multiple Reflections for Shear Wave Transducer

911122 50% Sugar Water, SQ wave,
2 gains, 1/9/08



50% Sugar Water, SQ Wave,
2 gains, 1/9/08 echo = 2



Data: Spectra for 6 SW solutions and water.
5 echoes each \rightarrow 35 FFTs

Self-Calibration Occurs with Multiple Reflections


- ▶ If transducer output changes from one data set to the next, EACH ECHO is affected in the same way.
- ▶ Reason: Each echo is dependent upon the very first echo. If the first echo changes, then each subsequent echo changes in the same manner.
- ▶ Experimental test, described in *J. Fluids Engineering*, Vol. 126, verifies this description.
- ▶ Result: Same transducer output is NOT REQUIRED in two data sets.



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Two Data Sets with Shear Wave Transducer Wedge



Determining the Reflection Coefficient from Multiple Reflections

- ▶ FFT Amplitude \propto (Reflection Coefficient) 2N
- ▶ For each echo, there are two reflections at interface.
- ▶ Using the same apparatus for water and liquid

$$V / W = R^{2N} / R_W^{2N}$$

where R = reflection coefficient for liquid

R_W = reflection coefficient for water

- ▶ Taking the natural logarithm

$$\ln (V / W) = 2 N \ln (R/R_W)$$

- ▶ Linear Relationship: $Y = N$ slope

where Slope = $2 \ln (R/R_W)$

$R/R_W = \exp (\text{slope}/2)$ for shear wave reflection



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Extension of Method

- ▶ Previous equation can be written as:

$$\ln V - \ln W = 2 N \ln (R/R_W)$$

- ▶ Write this equation for each of the P points shown in graph and sum:

$$\sum \ln V_i - \sum \ln W_i = 2 N P \ln (R/R_W)$$


- ▶ $[\ln V]_{AV} - [\ln W]_{AV} = 2 N \ln (R/R_W)$
- ▶ For each liquid, plot graph of $[\ln V]_{AV} - [\ln W]_{AV}$ versus echo number N and find slope of line.
- ▶ $R/R_W = \exp (\text{slope} / 2)$



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Determining Slope for Shear Wave Transducer Data




Slope = -0.103

$R/R_W = \exp(\text{slope}/2)$

$R/R_W = 0.950$


P = 5 points

Comparison of Experimental Data with Theoretical Calculations



▶ Next step >>>>> Theoretical Calculations

Theoretical Calculations



- ▶ Follows discussion in J. Krautkramer and H Krautkramer, *Ultrasonic Testing of Materials*, 4th, p 561-571.
- ▶ When $\alpha_T = 45^\circ$, a reflected longitudinal wave does not exist.

Theoretical Calculations (cont'd)

- ▶ When $\alpha_T = 45^\circ$, a reflected longitudinal wave does not exist.

$$\sin \alpha_L = (c_L/c_T) \sin \alpha_T > 1$$

- ▶ The angle α_L is imaginary and reflection coefficient R_{tt} is complex.
- ▶ Reflection coefficient = real part of R_{tt} .
- ▶ Details will be available soon in *Proceedings of Meetings in Acoustics*.
- ▶ Result: A formulation for R_{tt} is obtained that involves all of the parameters shown in last figure.

$$R_{tt} = f(Z_{liq}, \cos \alpha, \text{known material constants})$$

$$\text{where } Z_{liq} = \rho c$$



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Theoretical Calculations (cont'd)

- ▶ To compare experimental and theoretical data, use water and sugar water solutions with known density and velocity of sound for the experimental measurements of the reflection coefficient.
- ▶ Calculate R_{tt} for all liquids using the formulation using known density and velocity of sound for liquids.
- ▶ Plot (or compare) the experimental and theoretical values of
of $\left(\frac{\text{Refl Coeff for Liquid}}{\text{Refl Coeff for Water}} \right)$ vs. SW concentration
- ▶ Excellent agreement, shown on graph, between experimental data and theoretical calculations demonstrates the ability to determine the reflection coefficient experimentally.



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Determination of the Density and Velocity of Sound from Two Reflection Coefficients

- ▶ Use experimental reflection coefficients for the longitudinal wave and that for the shear wave to determine the two unknowns:

- Determine value for experimental reflection coefficient R_{tt} for the shear wave from

$$R_{tt} = R_{tt} W * \exp(\text{slope}/2)$$

- Recall that the reflection coefficient for the longitudinal wave led to a determination of the acoustic impedance Z_{liq} of the liquid.
- Substitute the experimental value of Z_{liq} into the formulation for the reflection coefficient for the shear wave.

$$R_{tt} = f(Z_{liq}, \cos \alpha, \text{known material constants})$$



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

Determination of the Density and Velocity of Sound from Two Reflection Coefficients (cont'd)

- Solve equation to obtain value of $\cos \alpha$.
- Knowing the value of α , the velocity of sound c in the liquid can be obtained from Snell's Law:

$$c = c_T (\sin \alpha / \sin \alpha_T)$$

▶ Density of liquid = Z_{liq} / c



Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965